

MAIN

100A OVERHEAD MAIN:

- For Use in All Non-DWP Areas for General Construction
- 100amp Main Breaker
- Receptacles:
 - (2) 20amp. 110volt GFCI
 - (1) 50amp. 220volt Temp Plug



100A UNDERGROUND MAIN:

- For Use in All Non-DWP Areas for General Construction
- 100amp Main Breaker
- Receptacles:
 - (2) 20amp. 110volt GFCI
 - (1) 50amp. 220volt Temp Plug



200A UNDERGROUND COMMERCIAL MAIN (DWP):

- For Use in DWP Areas (or as Required by Other Agencies)
- For Larger Construction Projects, Commercial Buildings, Trailers, Apartment Complexes, Tract Construction.
- Used to Feed Additional Equipment
- (1) 200amp Main Breaker
- NO Receptacles



200A UNDERGROUND DWP (w/PULL BOX) & 200A SUB PANEL 2:

- For Use in DWP Areas (or as Required by Other Agencies)
- For Commercial Construction & Double Wide Trailers
- (2) 100amp Breakers



800-992-7755

www.andygump.com

For inquiries, contact our
Customer Service Specialist